

# NEW

## MPP 350

### ... the easy solution for multiparameter measurings

Simultaneous measurements of pH, oxygen, conductivity, and temperature are time-saving and efficient. Especially with field measurements it is desirable to obtain all readings at the lowest possible effort. Together with the Multi 350i, the MPP 350 provides a complete and flexible system for field measurements. All measured data are displayed simultaneously. A computer interface for data transmitting; sensor protection; a built-in calibration sleeve and more provide all the field or lab technician needs. A battery stirrer for the DO sensor that is provided with cable lengths as of 10.94 yds (10 m) allows correct readings even in stagnant waters.

# VARIO

**You need a meter for quick and precise measurement without a great deal of laboratory work? Or an easy-to-use handheld instrument for complex tasks? The new VARIO is able to perform both!**

New from WTW: measuring technique turned on its head. The new VARIO Sets for pH/mV or conductivity measurement from WTW. Ergonomy and versatility with the well-known WTW quality.

The new VARIO has a lot to offer – and at an unbeatable price. The **design** has been developed from an ergonomic point of view: VARIO is small, lightweight, handy and the non-slip rubber housing makes it robust!

Simple measurement. Instead of keys, VARIO has an innovative touch screen: all functions can be easily accessed and set – using one hand.

Keyword: **power**. VARIO offers up to 1,500 hours continuous use – with a single normal 1.5 V battery (AA). In standby the low-power technology switches it off after ten minutes. Changing the battery is easier than with a flashlight.

And the **reliability**? The electrode glass is protected by an unbreakable plastic cover. The conical protective cap prevents electrode drips and drying-out.

### VARIO C<sub>ond</sub> – small but powerful:

Precision measurement technology with cable-free plug head measurement cells. For natural waters and ultrapure water, especially suited for service and maintenance of ultrapure water treatment systems.

### VARIO pH – robust and handy:

Proven pH measuring technology for manual metering in small volumes or for service purposes.

### All complete

Of course, the VARIO pH comes in handy case sets complete with combination electrode, DIN or S7 adapter, the VARIO C<sub>ond</sub> with 4 electrodes or ultrapure water measurement cells, plus accessories... simply ready to go.

## New Instruments

- Compact and robust
- Simultaneous measurement of pH, oxygen, conductivity, temperature
- Up to 100 m cable length



- Single-handed operation
- Ergonomic
- Touch screen

For more information, please contact us:

[ExpotechUSA](#)  
[10700 Rockley Road](#)  
[Houston, Texas 77099](#)  
[USA](#)

[281-496-0900 \[voice\]](#)

[281-496-0400 \[fax\]](#)

E-mail: [sales@expotechusa.com](mailto:sales@expotechusa.com)

Website: [www.ExpotechUSA.com](http://www.ExpotechUSA.com)